

Nanostructure strategies towards performance-enhanced perovskite solar cells

A. García-Martín^{1,*}, Z. Hu², L. Aigouy², J.M. García-Martín¹, M.-U. González¹, H.-J. Lin², M. Schoenauer-Sebag², L. Billot², P. Gredin³, M. Mortier³, Z. Chen²

¹ Instituto de Micro y Nanotecnología IMN-CNM, CSIC (CEI UAM+CSIC), Tres Cantos, Madrid, Spain

² LPEM, ESPCI Paris, PSL Research University, CNRS, Sorbonne Universités, Paris, France

³ Chimie ParisTech, PSL Research University, CNRS, Institut de Recherche de Chimie Paris, Paris, France

* a.garcia.martin@csic.es

Please indicate preference: (Invited)

Specify Technical Area: Energy and other Applications

Organic-inorganic hybrid perovskite solar cells have attracted much attention due to their high power conversion efficiency (>23%) and low-cost fabrication. Directions to further improve these solar cells include strategies to enhance their stability and their efficiency by modifying either the perovskite absorber layer or the electron/hole transport layer. For example, the transparent electron transport layer (ETL) can be an important tuning knob influencing the charge extraction, [1] light harvesting, [2] and stability [3] in these solar cells, or the use of up-conversion nanoparticles to get better performance in the near IR part of the visible spectrum. [4] Here we present two strategies based on nanostructuration, first a fundamental study of upconversion fluorescence enhancement effects near Au nanodisks by scanning near-field optical microscopy and second the effects of a nanocolumnar TiO₂ layer on the performance and the stability of Cs_{0.05}(FA_{0.83}MA_{0.17})_{0.95}Pb(I_{0.83}Br_{0.17})₃ perovskite solar cells. For the first case, the enhancement and localization of light near the metallic structures are directly visualized by using a single Er/Yb-codoped fluorescent nanocrystal glued at the end of a sharp scanning tip. [5] For the second we find that, compared to devices with planar TiO₂ ETLs, the TiO₂ nanocolumns can significantly enhance the power conversion efficiency of the perovskite solar cells by 17 % and prolong their shelf life. By analyzing the optical properties, solar cells characteristics, as well as transport/recombination properties by impedance spectroscopy, we observed light-trapping and reduced carrier recombination in solar cells associated with the use of TiO₂ nanocolumn arrays. [6]

References

- [1] S.S. Mali, et al., Chemistry of Materials 27, (2015) 1541
- [2] C. Liu, et al., Journal of Materials Chemistry A 5, (2017) 15970
- [3] M. Salado, et al., Nano Energy 35, (2017) 215
- [4] M. Bauch et al., Plasmonics 9, (2014) 781
- [5] L. Aigouy, et al., Nanoscale 11, (2019) 10365
- [6] Z. Hu, et al., ACS Appl. Mater. Interfaces 12, (2020) 5979